

RTA

CABINET STORE

May 08, 2024

Primary Grey Shaker Kitchen Cabinets Price List



Sink base

Model #	Item	Price
EG-CSF42	Primary Grey Shaker Corner Sink Front for 42" Space - 27" W	\$126.67
EG-SB30	Primary Grey Shaker Sink Base Cabinet - 30" W x 34.5" H	\$227.80
EG-SB33	Primary Grey Shaker Sink Base Cabinet - 33" W x 34.5" H	\$241.31
EG-SB36	Primary Grey Shaker Sink Base Cabinet - 36" W x 34.5" H	\$247.88
EG-SB42	Primary Grey Shaker Sink Base Cabinet w/ CS - 42" W x 34.5" H	\$284.38
EG-VSB36	Primary Grey Shaker Vanity Sink Base - 36" W x 34.5" H x 21" D	\$340.24
EG-VSB42	Primary Grey Shaker Vanity Sink Base - 42" W x 34.5" H x 21" D	\$376.75
EG-VSB48	Primary Grey Shaker Vanity Sink Base - 48" W x 34.5" H x 21" D	\$420.93

Filler

Model #	Item	Price
EG-FF396	Primary Grey Shaker Fluted Filler - 3" W x 96" H	\$88.35
EG-OLF330	Primary Grey Shaker Overlay Filler - 3" W x 30" H	\$31.03
EG-OLF336	Primary Grey Shaker Overlay Filler - 3" W x 36" H	\$36.14
EG-OLF342	Primary Grey Shaker Overlay Filler - 3" W x 42" H	\$41.61
EG-OLF630	Primary Grey Shaker Overlay Filler - 6" W x 30" H	\$62.44
EG-F396	Primary Grey Shaker Filler - 3" W x 96" H	\$48.92
EG-F696	Primary Grey Shaker Filler - 6" W x 96" H	\$98.20

End panel

Model #	Item	Price
EG-DWR3	Primary Grey Shaker Dish Washer End Panel	\$105.14
EG-BPLG4896	Primary Grey Shaker Back Panel (Long Grain) - 48" W x 96" H x 1/4" Thick	\$172.30
EG-OP3353	Primary Grey Shaker Oven Cabinet Overlay Panel - 33" W x 55" H	\$129.22
EG-TEP3096	Primary Grey Shaker Tall End Panel	\$185.08
EG-PSP4896	Primary Grey Shaker 1/2" Thick Finished Plywood Panel	\$286.95

Molding

Model #	Item	Price
EG-RCM8	Primary Grey Shaker Royal Crown Molding	\$130.33
EG-OCM8	Primary Grey Shaker Outside Corner Molding	\$23.00
EG-SHOE	Primary Grey Shaker Shoe Molding	\$18.62
EG-SCM8	Primary Grey Shaker Shaker Crown Molding	\$61.34
EG-BCM8	Primary Grey Shaker Large Crown Molding	\$125.23
EG-BEM8	Primary Grey Shaker Bottom Edge Molding (Narrow Light Rail)	\$62.44
EG-BAM8	Primary Grey Shaker Batten Molding	\$18.26
EG-FBM8	Primary Grey Shaker Furniture Base Molding	\$86.16
EG-CM8	Primary Grey Shaker Traditional Crown Molding	\$61.34
EG-COM8	Primary Grey Shaker Cove Crown Molding	\$102.59

Blind door

Model #	Item	Price
EG-BB36	Primary Grey Shaker Blind Base Cab for 36" to 39" Space - 30" W	\$301.55
EG-BB42	Primary Grey Shaker Blind Base Cab for 42" to 45" Space - 36" W	\$341.71
EG-BB48	Primary Grey Shaker Blind Base Cab for 48" to 51" Space - 48" W	\$376.02
EG-BW3636	Primary Grey Shaker Blind Wall Cabinet - 36" W x 36" H	\$241.31
EG-BW3642	Primary Grey Shaker Blind Wall Cabinet - 36" W x 42" H	\$303.01

Pantry

Model #	Item	Price
EG-P1884	Primary Grey Shaker Pantry - 18" W x 84" H	\$472.04
EG-P1890	Primary Grey Shaker Pantry - 18" W x 90" H	\$509.26
EG-P1896	Primary Grey Shaker Pantry - 18" W x 96" H	\$530.07

Oven

Model #	Item	Price
EG-OC3390	Primary Grey Shaker Oven Cabinet - 33" W x 90" H	\$765.54
EG-OC3396	Primary Grey Shaker Oven Cabinet - 33" W x 96" H	\$817.76
EG-OCD337	Primary Grey Shaker Oven Cabinet Drawer	\$198.24

Deep

Model #	Item	Price
EG-W361824	Primary Grey Shaker Deep Wall Cabinet - 36" W x 18" H x 24" D	\$211.37
EG-W362424	Primary Grey Shaker Deep Wall Cabinet - 36" W x 24" H x 24" D	\$245.70

Single door

Model #	Item	Price
EG-W930	Primary Grey Shaker Single Door Wall Cabinet - 9" W x 30" H	\$90.90
EG-W936	Primary Grey Shaker Single Door Wall Cabinet - 9" W x 36" H	\$102.94
EG-W942	Primary Grey Shaker Single Door Wall Cabinet - 9" W x 42" H	\$122.30
EG-W1230	Primary Grey Shaker Single Door Wall Cabinet - 12" W x 30" H	\$104.42
EG-W1236	Primary Grey Shaker Single Door Wall Cabinet - 12" W x 36" H	\$117.55
EG-W1242	Primary Grey Shaker Single Door Wall Cabinet - 12" W x 42" H	\$140.18
EG-W1530	Primary Grey Shaker Single Door Wall Cabinet - 15" W x 30" H	\$116.82
EG-W1536	Primary Grey Shaker Single Door Wall Cabinet - 15" W x 36" H	\$134.70
EG-W1542	Primary Grey Shaker Single Door Wall Cabinet - 15" W x 42" H	\$159.53
EG-W1830	Primary Grey Shaker Single Door Wall Cabinet - 18" W x 30" H	\$133.97
EG-W1836	Primary Grey Shaker Single Door Wall Cabinet - 18" W x 36" H	\$152.60

EG-W1842	Primary Grey Shaker Single Door Wall Cabinet - 18" W x 42" H	\$181.81
EG-W2130	Primary Grey Shaker Single Door Wall Cabinet - 21" W x 30" H	\$149.68
EG-W2136	Primary Grey Shaker Single Door Wall Cabinet - 21" W x 36" H	\$170.48
EG-W2142	Primary Grey Shaker Single Door Wall Cabinet - 21" W x 42" H	\$202.61
EG-VB15	Primary Grey Shaker Single Door Base Vanity - 15" W x 21" D	\$183.26
EG-VB18	Primary Grey Shaker Single Door Base Vanity-18"W x 34.5"H x 21"D	\$197.51
EG-B09	Primary Grey Shaker Single Door Full Height Base Cabinet - 9" W	\$131.05
EG-B12	Primary Grey Shaker Single Door Standard Base Cabinet - 12" W	\$180.34
EG-B15	Primary Grey Shaker Single Door Standard Base Cabinet - 15" W	\$196.76
EG-B18	Primary Grey Shaker Single Door Standard Base Cabinet - 18" W	\$212.12
EG-B21	Primary Grey Shaker Single Door Standard Base Cabinet - 21" W	\$229.26

Double door		
Model #	Item	Price
EG-B24-2	Primary Grey Shaker Double Door Standard Base Cabinet - 24" W	\$253.35
EG-B27	Primary Grey Shaker Double Door Standard Base Cabinet - 27" W	\$312.86
EG-B30	Primary Grey Shaker Double Door Standard Base Cabinet - 30" W	\$321.63
EG-B33	Primary Grey Shaker Double Door Standard Base Cabinet - 33" W	\$349.36
EG-B36	Primary Grey Shaker Double Door Standard Base Cabinet - 36" W	\$356.67
EG-V24-2	Primary Grey Shaker Double Door Vanity - 24" W x 34.5" H x 21"	\$174.86
EG-V27	Primary Grey Shaker Double Door Vanity - 27" W x 34.5" H x 21"	\$204.08
EG-V30	Primary Grey Shaker Double Door Vanity - 30" W x 34.5" H x 21"	\$211.37
EG-V33	Primary Grey Shaker Double Door Vanity - 33" W x 34.5" H x 21"	\$232.19
EG-V36	Primary Grey Shaker Double Door Vanity - 36" W x 34.5" H x 21"	\$246.42
EG-W2430-2	Primary Grey Shaker Double Door Wall Cabinet - 24" W x 30" H	\$178.16
EG-W2436-2	Primary Grey Shaker Double Door Wall Cabinet - 24" W x 36" H	\$207.72
EG-W2442-2	Primary Grey Shaker Double Door Wall Cabinet - 24" W x 42" H	\$239.84
EG-W2730	Primary Grey Shaker Double Door Wall Cabinet - 27" W x 30" H	\$198.96
EG-W2736	Primary Grey Shaker Double Door Wall Cabinet - 27" W x 36" H	\$224.89
EG-W2742	Primary Grey Shaker Double Door Wall Cabinet - 27" W x 42" H	\$267.22
EG-W3012	Primary Grey Shaker Double Door Wall Cabinet - 30" W x 12" H	\$93.09
EG-W3015	Primary Grey Shaker Double Door Wall Cabinet - 30" W x 15" H	\$115.36
EG-W3018	Primary Grey Shaker Double Door Wall Cabinet - 30" W x 18" H	\$148.95
EG-W3024	Primary Grey Shaker Double Door Wall Cabinet - 30" W x 24" H	\$182.54
EG-W3030	Primary Grey Shaker Double Door Wall Cabinet - 30" W x 30" H	\$205.54
EG-W3036	Primary Grey Shaker Double Door Wall Cabinet - 30" W x 36" H	\$243.50
EG-W3042	Primary Grey Shaker Double Door Wall Cabinet - 30" W x 42" H	\$289.13
EG-W3315	Primary Grey Shaker Double Door Wall Cabinet - 33" W x 15" H	\$125.96
EG-W3330	Primary Grey Shaker Double Door Wall Cabinet - 33" W x 30" H	\$229.26
EG-W3336	Primary Grey Shaker Double Door Wall Cabinet - 33" W x 36" H	\$261.40
EG-W3342	Primary Grey Shaker Double Door Wall Cabinet - 33" W x 42" H	\$309.93
EG-W3612	Primary Grey Shaker Double Door Wall Cabinet - 36" W x 12" H	\$115.36
EG-W3615	Primary Grey Shaker Double Door Wall Cabinet - 36" W x 15" H	\$128.87
EG-W3618	Primary Grey Shaker Double Door Wall Cabinet - 36" W x 18" H	\$171.21
EG-W3630	Primary Grey Shaker Double Door Wall Cabinet - 36" W x 30" H	\$237.67
EG-W3636	Primary Grey Shaker Double Door Wall Cabinet - 36" W x 36" H	\$279.27
EG-W3642	Primary Grey Shaker Double Door Wall Cabinet - 36" W x 42" H	\$331.48
EG-W3918	Primary Grey Shaker Double Door Wall Cabinet - 39" W x 18" H	\$182.54
EG-W3924	Primary Grey Shaker Double Door Wall Cabinet - 39" W x 24" H	\$219.76
EG-W3624	Primary Grey Shaker Double Door Wall Cabinet - 36" W x 24" H	\$204.81

Lazy susan

Model #	Item	Price
EG-LSB36	Primary Grey Shaker Lazy Susan Cabinet - 36" W x 24" D	\$645.26

Easy reach

Model #	Item	Price
EG-ER36	Primary Grey Shaker Easy Reach Base Cabinet - 36" W x 24" D	\$380.39

Drawer base

Model #	Item	Price
EG-DB12-3	Primary Grey Shaker Drawer Base Cabinet - 12" W	\$272.70
EG-DB15-3	Primary Grey Shaker Drawer Base Cabinet - 15" W	\$301.55
EG-DB18-3	Primary Grey Shaker Drawer Base Cabinet - 18" W	\$323.81
EG-DB21-3	Primary Grey Shaker Drawer Base Cabinet - 21" W	\$346.45
EG-DB24-3	Primary Grey Shaker Drawer Base Cabinet - 24" W	\$370.17
EG-DB30-3	Primary Grey Shaker Drawer Base Cabinet - 30" W	\$422.38
EG-VDB12	Primary Grey Shaker Vanity Drawer Base - 12" W x 34.5" H x 21"	\$267.94
EG-VDB15	Primary Grey Shaker Vanity Drawer Base - 15" W x 34.5" H x 21"	\$289.85
EG-VDB18	Primary Grey Shaker Vanity Drawer Base - 18" W x 34.5" H x 21"	\$312.14
EG-VDB21	Primary Grey Shaker Vanity Drawer Base - 21" W x 34.5" H x 21"	\$349.36
EG-VDB24	Primary Grey Shaker Vanity Drawer Base - 24" W x 34.5" H x 21"	\$386.60

Wine Rack

Model #	Item	Price
EG-WR3018	Primary Grey Shaker Wine Rack - 30" W x 18" H x 12" D	\$163.18

Other

Model #	Item	Price
EG-SPRAYCAN	Primary Grey Shaker Spray Can	\$7.30
EG-TBUNFOOT	Primary Grey Shaker Bunfoot	\$73.01
EG-TBUNFOOT2	Primary Grey Shaker Transitional Bunfoot	\$73.01
EG-TKS8	Primary Grey Shaker Toe Kick	\$15.70
EG-TPOSTP3	Primary Grey Shaker Turned Post - 3" W x 35.5" H	\$131.42
EG-TPOSTP5	Primary Grey Shaker Turned Post - 5" W x 35.5" H	\$200.41
EG-TUKIT	Primary Grey Shaker Touchup Kit	\$5.48
EG-LRM8	Primary Grey Shaker Traditional Light Rail	\$125.23
EG-SCRIBE	Primary Grey Shaker Scribe	\$19.71
EG-SHELF1296	Primary Grey Shaker Shelf - 96" W x 12" D	\$171.21
EG-CORMS	Primary Grey Shaker Basic Medium Corbel - 10.5" H	\$35.06
EG-CORT	Primary Grey Shaker Transitional Corbel	\$97.12
EG-CORT Box5	Primary Grey Shaker Transitional Medium Corbel - 10.5" H	\$69.36
EG-CW2430	Primary Grey Shaker Corner Wall Cabinet - 24" W x 30" H	\$223.42
EG-CW2436	Primary Grey Shaker Corner Wall Cabinet - 24" W x 36" H	\$250.80
EG-CW2442	Primary Grey Shaker Corner Wall Cabinet - 24" W x 42" H	\$317.98
EG-CW2736	Primary Grey Shaker Corner Wall Cabinet - 27" W x 36" H	\$286.58
EG-CW2742	Primary Grey Shaker Corner Wall Cabinet - 27" W x 42" H	\$340.24
EG-BBP4842	Primary Grey Shaker Bead Board - 48" W x 42" H x 0.25" D	\$97.12
EG-BCE1596	Primary Grey Shaker Book Case End - 1.5" W x 96" H x 15" D	\$141.64