

# RTA

## CABINET STORE

June 22, 2026

### Primary Grey Shaker Kitchen Cabinets Price List



#### Sink base

Model #	Item	Price
EG-CSF42	Primary Grey Shaker Corner Sink Front for 42" Space - 27" W	\$149.37
EG-SB30	Primary Grey Shaker Sink Base Cabinet - 30" W x 34.5" H	\$268.60
EG-SB33	Primary Grey Shaker Sink Base Cabinet - 33" W x 34.5" H	\$284.54
EG-SB36	Primary Grey Shaker Sink Base Cabinet - 36" W x 34.5" H	\$292.28
EG-SB42	Primary Grey Shaker Sink Base Cabinet w/ CS - 42" W x 34.5" H	\$335.32
EG-VSB36	Primary Grey Shaker Vanity Sink Base - 36" W x 34.5" H x 21" D	\$401.19
EG-VSB42	Primary Grey Shaker Vanity Sink Base - 42" W x 34.5" H x 21" D	\$444.24
EG-VSB48	Primary Grey Shaker Vanity Sink Base - 48" W x 34.5" H x 21" D	\$496.34

#### Filler

Model #	Item	Price
EG-FF396	Primary Grey Shaker Fluted Filler - 3" W x 96" H	\$104.17
EG-OLF330	Primary Grey Shaker Overlay for 3" x 30" Filler	\$36.59
EG-OLF336	Primary Grey Shaker Overlay for 3" x 36" Filler	\$42.62
EG-OLF342	Primary Grey Shaker Overlay for 3" x 42" Filler	\$49.06
EG-OLF630	Primary Grey Shaker Overlay for 6" x 30" Filler	\$73.62
EG-F396	Primary Grey Shaker Filler - 3" W x 96" H	\$57.68
EG-F696	Primary Grey Shaker Filler - 6" W x 96" H	\$115.79

#### End panel

Model #	Item	Price
EG-DWR3	Primary Grey Shaker Dish Washer End Panel	\$123.98
EG-BPLG4896	Primary Grey Shaker Back Panel (Long Grain) - 48" W x 96" H x 1/4" Thick	\$203.17
EG-OP3353	Primary Grey Shaker Oven Cabinet Overlay Panel - 33" W x 55" H	\$152.38
EG-TEP3096	Primary Grey Shaker Tall End Panel	\$218.24
EG-PSP4896	Primary Grey Shaker 1/2" Thick Finished Plywood Panel	\$338.36

#### Molding

Model #	Item	Price
EG-RCM8	Primary Grey Shaker Royal Crown Molding	\$153.68
EG-OCM8	Primary Grey Shaker Outside Corner Molding	\$27.12
EG-SHOE	Primary Grey Shaker Shoe Molding	\$21.96
EG-SCM8	Primary Grey Shaker Shaker Crown Molding	\$72.33
EG-BCM8	Primary Grey Shaker Large Crown Molding	\$147.67
EG-BEM8	Primary Grey Shaker Bottom Edge Molding (Narrow Light Rail)	\$73.62
EG-BAM8	Primary Grey Shaker Batten Molding	\$21.54
EG-FBM8	Primary Grey Shaker Furniture Base Molding	\$101.59
EG-CM8	Primary Grey Shaker Traditional Crown Molding	\$72.33
EG-COM8	Primary Grey Shaker Cove Crown Molding	\$120.98

## Blind door

Model #	Item	Price
EG-BB36	Primary Grey Shaker Blind Base Cab for 36" to 39" Space - 30" W	\$355.57
EG-BB42	Primary Grey Shaker Blind Base Cab for 42" to 45" Space - 36" W	\$402.92
EG-BB48	Primary Grey Shaker Blind Base Cab for 48" to 51" Space - 48" W	\$443.38
EG-BW3636	Primary Grey Shaker Blind Wall Cabinet - 36" W x 36" H	\$284.54
EG-BW3642	Primary Grey Shaker Blind Wall Cabinet - 36" W x 42" H	\$357.28
EG-BW3630	Primary Grey Shaker Blind Wall Cabinet - 36" W x 30" H	\$261.62

## Pantry

Model #	Item	Price
EG-P1884	Primary Grey Shaker Pantry - 18" W x 84" H	\$556.60
EG-P1890	Primary Grey Shaker Pantry - 18" W x 90" H	\$600.50
EG-P1896	Primary Grey Shaker Pantry - 18" W x 96" H	\$625.03

## Oven

Model #	Item	Price
EG-OC3390	Primary Grey Shaker Oven Cabinet - 33" W x 90" H	\$902.68
EG-OC3396	Primary Grey Shaker Oven Cabinet - 33" W x 96" H	\$964.25
EG-OCD337	Primary Grey Shaker Oven Cabinet Drawer	\$233.74

## Deep

Model #	Item	Price
EG-W361824	Primary Grey Shaker Deep Wall Cabinet - 36" W x 18" H x 24" D	\$249.23
EG-W362424	Primary Grey Shaker Deep Wall Cabinet - 36" W x 24" H x 24" D	\$289.71

## Single door

Model #	Item	Price
EG-W930	Primary Grey Shaker Single Door Wall Cabinet - 9" W x 30" H	\$107.18
EG-W936	Primary Grey Shaker Single Door Wall Cabinet - 9" W x 36" H	\$121.40
EG-W942	Primary Grey Shaker Single Door Wall Cabinet - 9" W x 42" H	\$144.20
EG-W1230	Primary Grey Shaker Single Door Wall Cabinet - 12" W x 30" H	\$123.12
EG-W1236	Primary Grey Shaker Single Door Wall Cabinet - 12" W x 36" H	\$138.60
EG-W1242	Primary Grey Shaker Single Door Wall Cabinet - 12" W x 42" H	\$165.28
EG-W1530	Primary Grey Shaker Single Door Wall Cabinet - 15" W x 30" H	\$137.74
EG-W1536	Primary Grey Shaker Single Door Wall Cabinet - 15" W x 36" H	\$158.83
EG-W1542	Primary Grey Shaker Single Door Wall Cabinet - 15" W x 42" H	\$188.12
EG-W1830	Primary Grey Shaker Single Door Wall Cabinet - 18" W x 30" H	\$157.98

EG-W1836	Primary Grey Shaker Single Door Wall Cabinet - 18" W x 36" H	\$179.94
EG-W1842	Primary Grey Shaker Single Door Wall Cabinet - 18" W x 42" H	\$214.37
EG-W2130	Primary Grey Shaker Single Door Wall Cabinet - 21" W x 30" H	\$176.49
EG-W2136	Primary Grey Shaker Single Door Wall Cabinet - 21" W x 36" H	\$201.02
EG-W2142	Primary Grey Shaker Single Door Wall Cabinet - 21" W x 42" H	\$238.91
EG-VB15	Primary Grey Shaker Single Door Base Vanity - 15" W x 21" D	\$216.10
EG-VB18	Primary Grey Shaker Single Door Base Vanity-18"W x 34.5"H x 21"D	\$232.90
EG-B09	Primary Grey Shaker Single Door Full Height Base Cabinet - 9" W	\$154.52
EG-B12	Primary Grey Shaker Single Door Standard Base Cabinet - 12" W	\$212.65
EG-B15	Primary Grey Shaker Single Door Standard Base Cabinet - 15" W	\$232.01
EG-B18	Primary Grey Shaker Single Door Standard Base Cabinet - 18" W	\$250.11
EG-B21	Primary Grey Shaker Single Door Standard Base Cabinet - 21" W	\$270.33

## Double door

Model #	Item	Price
EG-B24-2	Primary Grey Shaker Double Door Standard Base Cabinet - 24" W	\$298.73
EG-B27	Primary Grey Shaker Double Door Standard Base Cabinet - 27" W	\$368.91
EG-B30	Primary Grey Shaker Double Door Standard Base Cabinet - 30" W	\$379.24
EG-B33	Primary Grey Shaker Double Door Standard Base Cabinet - 33" W	\$411.94
EG-B36	Primary Grey Shaker Double Door Standard Base Cabinet - 36" W	\$420.56
EG-V24-2	Primary Grey Shaker Double Door Vanity - 24" W x 34.5" H x 21"	\$206.18
EG-V27	Primary Grey Shaker Double Door Vanity - 27" W x 34.5" H x 21"	\$240.64
EG-V30	Primary Grey Shaker Double Door Vanity - 30" W x 34.5" H x 21"	\$249.23
EG-V33	Primary Grey Shaker Double Door Vanity - 33" W x 34.5" H x 21"	\$273.78
EG-V36	Primary Grey Shaker Double Door Vanity - 36" W x 34.5" H x 21"	\$290.56
EG-W2430-2	Primary Grey Shaker Double Door Wall Cabinet - 24" W x 30" H	\$210.08
EG-W2436-2	Primary Grey Shaker Double Door Wall Cabinet - 24" W x 36" H	\$244.93
EG-W2442-2	Primary Grey Shaker Double Door Wall Cabinet - 24" W x 42" H	\$282.80
EG-W2730	Primary Grey Shaker Double Door Wall Cabinet - 27" W x 30" H	\$234.61
EG-W2736	Primary Grey Shaker Double Door Wall Cabinet - 27" W x 36" H	\$265.18
EG-W2742	Primary Grey Shaker Double Door Wall Cabinet - 27" W x 42" H	\$315.08
EG-W3012	Primary Grey Shaker Double Door Wall Cabinet - 30" W x 12" H	\$109.77
EG-W3015	Primary Grey Shaker Double Door Wall Cabinet - 30" W x 15" H	\$136.04
EG-W3018	Primary Grey Shaker Double Door Wall Cabinet - 30" W x 18" H	\$175.63
EG-W3024	Primary Grey Shaker Double Door Wall Cabinet - 30" W x 24" H	\$215.23
EG-W3030	Primary Grey Shaker Double Door Wall Cabinet - 30" W x 30" H	\$242.37
EG-W3036	Primary Grey Shaker Double Door Wall Cabinet - 30" W x 36" H	\$287.12
EG-W3042	Primary Grey Shaker Double Door Wall Cabinet - 30" W x 42" H	\$340.94
EG-W3315	Primary Grey Shaker Double Door Wall Cabinet - 33" W x 15" H	\$148.51
EG-W3330	Primary Grey Shaker Double Door Wall Cabinet - 33" W x 30" H	\$270.33
EG-W3336	Primary Grey Shaker Double Door Wall Cabinet - 33" W x 36" H	\$308.23
EG-W3342	Primary Grey Shaker Double Door Wall Cabinet - 33" W x 42" H	\$365.44
EG-W3612	Primary Grey Shaker Double Door Wall Cabinet - 36" W x 12" H	\$136.04
EG-W3615	Primary Grey Shaker Double Door Wall Cabinet - 36" W x 15" H	\$151.96
EG-W3618	Primary Grey Shaker Double Door Wall Cabinet - 36" W x 18" H	\$201.89
EG-W3630	Primary Grey Shaker Double Door Wall Cabinet - 36" W x 30" H	\$280.24
EG-W3636	Primary Grey Shaker Double Door Wall Cabinet - 36" W x 36" H	\$329.30
EG-W3642	Primary Grey Shaker Double Door Wall Cabinet - 36" W x 42" H	\$390.86
EG-W3918	Primary Grey Shaker Double Door Wall Cabinet - 39" W x 18" H	\$215.23
EG-W3924	Primary Grey Shaker Double Door Wall Cabinet - 39" W x 24" H	\$259.12
EG-W3624	Primary Grey Shaker Double Door Wall Cabinet - 36" W x 24" H	\$241.50

Model #	Item	Price
EG-LSB36	Primary Grey Shaker Lazy Susan Cabinet - 36" W x 24" D	\$760.85

## Easy reach

Model #	Item	Price
EG-WER2430	Primary Grey Shaker Wall Easy Reach Cabinet - 24" W x 24" D x 30" H	\$304.78
EG-WER2436	Primary Grey Shaker Wall Easy Reach Cabinet - 24" W x 24" D x 36" H	\$323.65
EG-WER2442	Primary Grey Shaker Wall Easy Reach Cabinet - 24" W x 24" D x 42" H	\$370.61
EG-ER36	Primary Grey Shaker Easy Reach Base Cabinet - 36" W x 24" D	\$448.54

## Drawer base

Model #	Item	Price
EG-DB12-3	Primary Grey Shaker Drawer Base Cabinet - 12" W	\$321.56
EG-DB15-3	Primary Grey Shaker Drawer Base Cabinet - 15" W	\$355.57
EG-DB18-3	Primary Grey Shaker Drawer Base Cabinet - 18" W	\$381.82
EG-DB21-3	Primary Grey Shaker Drawer Base Cabinet - 21" W	\$408.51
EG-DB24-3	Primary Grey Shaker Drawer Base Cabinet - 24" W	\$436.48
EG-DB30-3	Primary Grey Shaker Drawer Base Cabinet - 30" W	\$498.04
EG-VDB12	Primary Grey Shaker Vanity Drawer Base - 12" W x 34.5" H x 21"	\$315.94
EG-VDB15	Primary Grey Shaker Vanity Drawer Base - 15" W x 34.5" H x 21"	\$341.78
EG-VDB18	Primary Grey Shaker Vanity Drawer Base - 18" W x 34.5" H x 21"	\$368.06
EG-VDB21	Primary Grey Shaker Vanity Drawer Base - 21" W x 34.5" H x 21"	\$411.94
EG-VDB24	Primary Grey Shaker Vanity Drawer Base - 24" W x 34.5" H x 21"	\$455.86

## Wine Rack

Model #	Item	Price
EG-WR3018	Primary Grey Shaker Wine Rack - 30" W x 18" H x 12" D	\$192.42

## Other

Model #	Item	Price
EG-SPRAYCAN	Primary Grey Shaker Spray Can	\$8.60
EG-TBUNFOOT	Primary Grey Shaker Bunfoot	\$86.09
EG-TBUNFOOT2	Primary Grey Shaker Transitional Bunfoot	\$86.09
EG-TKS8	Primary Grey Shaker Toe Kick	\$18.52
EG-TPOSTP3	Primary Grey Shaker Turned Post - 3" W x 35.5" H	\$154.96
EG-TPOSTP5	Primary Grey Shaker Turned Post - 5" W x 35.5" H	\$236.30
EG-TUKIT	Primary Grey Shaker Touchup Kit	\$39.92
EG-LRM8	Primary Grey Shaker Traditional Light Rail	\$147.67
EG-SCRIBE	Primary Grey Shaker Scribe	\$23.24
EG-SHELF1296	Primary Grey Shaker Shelf - 96" W x 12" D	\$201.89
EG-CORMSM	Primary Grey Shaker Basic Medium Corbel - 10.5" H	\$41.33
EG-CORT	Primary Grey Shaker Transitional Corbel	\$114.52
EG-CORT Box5	Primary Grey Shaker Transitional Medium Corbel - 10.5" H	\$81.79
EG-CW2430	Primary Grey Shaker Corner Wall Cabinet - 24" W x 30" H	\$263.45
EG-CW2436	Primary Grey Shaker Corner Wall Cabinet - 24" W x 36" H	\$295.72
EG-CW2442	Primary Grey Shaker Corner Wall Cabinet - 24" W x 42" H	\$374.95
EG-CW2736	Primary Grey Shaker Corner Wall Cabinet - 27" W x 36" H	\$337.93
EG-CW2742	Primary Grey Shaker Corner Wall Cabinet - 27" W x 42" H	\$401.19
EG-BBP4842	Primary Grey Shaker Bead Board - 48" W x 42" H x 0.25" D	\$114.52
EG-BCE1508	Primary Grey Shaker Back Case End - 15" W x 96" H x 15" D	\$167.04

