

RTA

CABINET STORE

April 03, 2026

Primary White Shaker Kitchen Cabinets Price List



Sink base

| Model # | Item | Price |
|----------|---|----------|
| EW-CSF42 | Primary White Shaker Corner Sink Front for 42" Space - 27" W | \$152.65 |
| EW-SB30 | Primary White Shaker Sink Base Cabinet - 30" W x 34.5" H | \$274.50 |
| EW-SB33 | Primary White Shaker Sink Base Cabinet - 33" W x 34.5" H | \$290.79 |
| EW-SB36 | Primary White Shaker Sink Base Cabinet - 36" W x 34.5" H | \$298.70 |
| EW-SB42 | Primary White Shaker Sink Base Cabinet w/ CS - 42" W x 34.5" H | \$342.69 |
| EW-VSB36 | Primary White Shaker Vanity Sink Base - 36" W x 34.5" H x 21" D | \$410.01 |
| EW-VSB42 | Primary White Shaker Vanity Sink Base - 42" W x 34.5" H x 21" D | \$454.00 |
| EW-VSB48 | Primary White Shaker Vanity Sink Base - 48" W x 34.5" H x 21" D | \$507.24 |

Filler

| Model # | Item | Price |
|-----------|---|----------|
| EW-FF396 | Primary White Shaker Fluted Filler - 3" W x 96" H | \$106.46 |
| EW-OLF330 | Primary White Shaker Overlay for 3" x 30" Filler | \$37.39 |
| EW-OLF336 | Primary White Shaker Overlay for 3" x 36" Filler | \$43.55 |
| EW-OLF342 | Primary White Shaker Overlay for 3" x 42" Filler | \$50.14 |
| EW-OLF630 | Primary White Shaker Overlay for 6" x 30" Filler | \$75.24 |
| EW-F396 | Primary White Shaker Filler - 3" W x 96" H | \$58.94 |
| EW-F696 | Primary White Shaker Filler - 6" W x 96" H | \$118.34 |

End panel

| Model # | Item | Price |
|-------------|---|----------|
| EW-DWR3 | Primary White Shaker Dish Washer End Panel | \$126.71 |
| EW-BPLG4896 | Primary White Shaker Back Panel (Long Grain) - 48" W x 96" H x 1/4" Thick | \$208.09 |
| EW-OP3353 | Primary White Shaker Oven Cabinet Overlay Panel - 33" W x 55" H | \$155.73 |
| EW-TEP3096 | Primary White Shaker Tall End Panel | \$223.03 |
| EW-PSP4896 | Primary White Shaker 1/2" Thick Finished Plywood Panel | \$345.79 |

Melina

| Model # | Item | Price |
|---------|--|----------|
| EW-RCM8 | Primary White Shaker Royal Crown Molding | \$157.06 |
| EW-OCM8 | Primary White Shaker Outside Corner Molding | \$27.71 |
| EW-SHOE | Primary White Shaker Shoe Molding | \$22.44 |
| EW-SCM8 | Primary White Shaker Shaker Crown Molding | \$73.92 |
| EW-BCM8 | Primary White Shaker Large Crown Molding | \$150.91 |
| EW-BEM8 | Primary White Shaker Bottom Edge Molding (Narrow Light Rail) | \$75.24 |
| EW-BAM8 | Primary White Shaker Batten Molding | \$22.01 |
| EW-FBM8 | Primary White Shaker Furniture Base Molding | \$103.82 |
| EW-CM8 | Primary White Shaker Traditional Crown Molding | \$73.92 |
| EW-COM8 | Primary White Shaker Cove Crown Molding | \$123.64 |

Blind door

| Model # | Item | Price |
|-----------|--|----------|
| EW-BB36 | Primary White Shaker Blind Base Cab for 36" to 39" Space - 30" W | \$363.38 |
| EW-BB42 | Primary White Shaker Blind Base Cab for 42" to 45" Space - 36" W | \$411.77 |
| EW-BB48 | Primary White Shaker Blind Base Cab for 48" to 51" Space - 48" W | \$453.13 |
| EW-BW3636 | Primary White Shaker Blind Wall Cabinet - 36" W x 36" H | \$290.79 |
| EW-BW3642 | Primary White Shaker Blind Wall Cabinet - 36" W x 42" H | \$365.13 |
| EW-BW3630 | Primary White Shaker Blind Wall Cabinet - 36" W x 30" H | \$267.37 |

Pantry

| Model # | Item | Price |
|----------|---|----------|
| EW-P1884 | Primary White Shaker Pantry - 18" W x 84" H | \$568.83 |
| EW-P1890 | Primary White Shaker Pantry - 18" W x 90" H | \$613.69 |
| EW-P1896 | Primary White Shaker Pantry - 18" W x 96" H | \$638.76 |

Oven

| Model # | Item | Price |
|-----------|---|----------|
| EW-OC3390 | Primary White Shaker Oven Cabinet - 33" W x 90" H | \$922.51 |
| EW-OC3396 | Primary White Shaker Oven Cabinet - 33" W x 96" H | \$985.44 |
| EW-OCD337 | Primary White Shaker Oven Cabinet Drawer | \$238.88 |

Deep

| Model # | Item | Price |
|------------|--|----------|
| EW-W361824 | Primary White Shaker Deep Wall Cabinet - 36" W x 18" H x 24" D | \$254.71 |
| EW-W362424 | Primary White Shaker Deep Wall Cabinet - 36" W x 24" H x 24" D | \$296.08 |

Single door

| Model # | Item | Price |
|----------|---|----------|
| EW-W930 | Primary White Shaker Single Door Wall Cabinet - 9" W x 30" H | \$109.54 |
| EW-W936 | Primary White Shaker Single Door Wall Cabinet - 9" W x 36" H | \$124.06 |
| EW-W942 | Primary White Shaker Single Door Wall Cabinet - 9" W x 42" H | \$147.37 |
| EW-W1230 | Primary White Shaker Single Door Wall Cabinet - 12" W x 30" H | \$125.83 |
| EW-W1236 | Primary White Shaker Single Door Wall Cabinet - 12" W x 36" H | \$141.65 |
| EW-W1242 | Primary White Shaker Single Door Wall Cabinet - 12" W x 42" H | \$168.91 |
| EW-W1530 | Primary White Shaker Single Door Wall Cabinet - 15" W x 30" H | \$140.77 |
| EW-W1536 | Primary White Shaker Single Door Wall Cabinet - 15" W x 36" H | \$162.32 |
| EW-W1542 | Primary White Shaker Single Door Wall Cabinet - 15" W x 42" H | \$192.25 |
| EW-W1830 | Primary White Shaker Single Door Wall Cabinet - 18" W x 30" H | \$161.45 |

| | | |
|----------|---|----------|
| EW-W1836 | Primary White Shaker Single Door Wall Cabinet - 18" W x 36" H | \$183.90 |
| EW-W1842 | Primary White Shaker Single Door Wall Cabinet - 18" W x 42" H | \$219.09 |
| EW-W2130 | Primary White Shaker Single Door Wall Cabinet - 21" W x 30" H | \$180.37 |
| EW-W2136 | Primary White Shaker Single Door Wall Cabinet - 21" W x 36" H | \$205.43 |
| EW-W2142 | Primary White Shaker Single Door Wall Cabinet - 21" W x 42" H | \$244.17 |
| EW-VB15 | Primary White Shaker Single Door Base Vanity - 15" W x 21" D | \$220.85 |
| EW-VB18 | Primary White Shaker Single Door Base Vanity-18"W x 34.5"H x 21"D | \$238.01 |
| EW-B12 | Primary White Shaker Single Door Standard Base Cabinet - 12" W | \$217.32 |
| EW-B09 | Primary White Shaker Single Door Full Height Base Cabinet - 9" W | \$157.92 |
| EW-B15 | Primary White Shaker Single Door Standard Base Cabinet - 15" W | \$237.11 |
| EW-B18 | Primary White Shaker Single Door Standard Base Cabinet - 18" W | \$255.61 |
| EW-B21 | Primary White Shaker Single Door Standard Base Cabinet - 21" W | \$276.27 |

Double door

| Model # | Item | Price |
|------------|---|----------|
| EW-B24-2 | Primary White Shaker Double Door Standard Base Cabinet - 24" W | \$305.29 |
| EW-B27 | Primary White Shaker Double Door Standard Base Cabinet - 27" W | \$377.01 |
| EW-B30 | Primary White Shaker Double Door Standard Base Cabinet - 30" W | \$387.57 |
| EW-B33 | Primary White Shaker Double Door Standard Base Cabinet - 33" W | \$421.00 |
| EW-B36 | Primary White Shaker Double Door Standard Base Cabinet - 36" W | \$429.80 |
| EW-V24-2 | Primary White Shaker Double Door Vanity - 24" W x 34.5" H x 21" | \$210.71 |
| EW-V27 | Primary White Shaker Double Door Vanity - 27" W x 34.5" H x 21" | \$245.93 |
| EW-V30 | Primary White Shaker Double Door Vanity - 30" W x 34.5" H x 21" | \$254.71 |
| EW-V33 | Primary White Shaker Double Door Vanity - 33" W x 34.5" H x 21" | \$279.80 |
| EW-V36 | Primary White Shaker Double Door Vanity - 36" W x 34.5" H x 21" | \$296.95 |
| EW-W2430-2 | Primary White Shaker Double Door Wall Cabinet - 24" W x 30" H | \$214.70 |
| EW-W2436-2 | Primary White Shaker Double Door Wall Cabinet - 24" W x 36" H | \$250.31 |
| EW-W2442-2 | Primary White Shaker Double Door Wall Cabinet - 24" W x 42" H | \$289.01 |
| EW-W2730 | Primary White Shaker Double Door Wall Cabinet - 27" W x 30" H | \$239.76 |
| EW-W2736 | Primary White Shaker Double Door Wall Cabinet - 27" W x 36" H | \$271.01 |
| EW-W2742 | Primary White Shaker Double Door Wall Cabinet - 27" W x 42" H | \$322.01 |
| EW-W3012 | Primary White Shaker Double Door Wall Cabinet - 30" W x 12" H | \$112.18 |
| EW-W3015 | Primary White Shaker Double Door Wall Cabinet - 30" W x 15" H | \$139.02 |
| EW-W3018 | Primary White Shaker Double Door Wall Cabinet - 30" W x 18" H | \$179.49 |
| EW-W3024 | Primary White Shaker Double Door Wall Cabinet - 30" W x 24" H | \$219.96 |
| EW-W3030 | Primary White Shaker Double Door Wall Cabinet - 30" W x 30" H | \$247.69 |
| EW-W3036 | Primary White Shaker Double Door Wall Cabinet - 30" W x 36" H | \$293.42 |
| EW-W3042 | Primary White Shaker Double Door Wall Cabinet - 30" W x 42" H | \$348.43 |
| EW-W3315 | Primary White Shaker Double Door Wall Cabinet - 33" W x 15" H | \$151.77 |
| EW-W3330 | Primary White Shaker Double Door Wall Cabinet - 33" W x 30" H | \$276.27 |
| EW-W3336 | Primary White Shaker Double Door Wall Cabinet - 33" W x 36" H | \$315.00 |
| EW-W3342 | Primary White Shaker Double Door Wall Cabinet - 33" W x 42" H | \$373.48 |
| EW-W3612 | Primary White Shaker Double Door Wall Cabinet - 36" W x 12" H | \$139.02 |
| EW-W3615 | Primary White Shaker Double Door Wall Cabinet - 36" W x 15" H | \$155.29 |
| EW-W3618 | Primary White Shaker Double Door Wall Cabinet - 36" W x 18" H | \$206.33 |
| EW-W3630 | Primary White Shaker Double Door Wall Cabinet - 36" W x 30" H | \$286.40 |
| EW-W3636 | Primary White Shaker Double Door Wall Cabinet - 36" W x 36" H | \$336.53 |
| EW-W3642 | Primary White Shaker Double Door Wall Cabinet - 36" W x 42" H | \$399.45 |
| EW-W3918 | Primary White Shaker Double Door Wall Cabinet - 39" W x 18" H | \$219.96 |
| EW-W3924 | Primary White Shaker Double Door Wall Cabinet - 39" W x 24" H | \$264.81 |
| EW-W3624 | Primary White Shaker Double Door Wall Cabinet - 36" W x 24" H | \$246.81 |

| Model # | Item | Price |
|----------|---|----------|
| EW-LSB36 | Primary White Shaker Lazy Susan Cabinet - 36" W x 24" D | \$777.57 |

Easy reach

| Model # | Item | Price |
|------------|--|----------|
| EW-WER2430 | Primary White Shaker Wall Easy Reach Cabinet - 24" W x 24" D x 30" H | \$311.48 |
| EW-WER2436 | Primary White Shaker Wall Easy Reach Cabinet - 24" W x 24" D x 36" H | \$330.76 |
| EW-WER2442 | Primary White Shaker Wall Easy Reach Cabinet - 24" W x 24" D x 42" H | \$378.76 |
| EW-ER36 | Primary White Shaker Easy Reach Base Cabinet - 36" W x 24" D | \$458.39 |

Drawer base

| Model # | Item | Price |
|-----------|---|----------|
| EW-DB12-3 | Primary White Shaker Drawer Base Cabinet - 12" W | \$328.62 |
| EW-DB15-3 | Primary White Shaker Drawer Base Cabinet - 15" W | \$363.38 |
| EW-DB18-3 | Primary White Shaker Drawer Base Cabinet - 18" W | \$390.21 |
| EW-DB21-3 | Primary White Shaker Drawer Base Cabinet - 21" W | \$417.48 |
| EW-DB24-3 | Primary White Shaker Drawer Base Cabinet - 24" W | \$446.08 |
| EW-DB30-3 | Primary White Shaker Drawer Base Cabinet - 30" W | \$477.24 |
| EW-VDB12 | Primary White Shaker Vanity Drawer Base - 12" W x 34.5" H x 21" | \$322.89 |
| EW-VDB15 | Primary White Shaker Vanity Drawer Base - 15" W x 34.5" H x 21" | \$349.29 |
| EW-VDB18 | Primary White Shaker Vanity Drawer Base - 18" W x 34.5" H x 21" | \$376.14 |
| EW-VDB21 | Primary White Shaker Vanity Drawer Base - 21" W x 34.5" H x 21" | \$421.00 |
| EW-VDB24 | Primary White Shaker Vanity Drawer Base - 24" W x 34.5" H x 21" | \$465.88 |

Wine Rack

| Model # | Item | Price |
|-----------|--|----------|
| EW-WR3018 | Primary White Shaker Wine Rack - 30" W x 18" H x 12" D | \$196.65 |

Other

| Model # | Item | Price |
|--------------|---|----------|
| EW-SPRAYCAN | Primary White Shaker Spray Can | \$8.79 |
| EW-TBUNFOOT | Primary White Shaker Bunfoot | \$87.98 |
| EW-TBUNFOOT2 | Primary White Shaker Transitional Bunfoot | \$87.98 |
| EW-TKS8 | Primary White Shaker Toe Kick | \$18.93 |
| EW-TPOSTP3 | Primary White Shaker Turned Post - 3" W x 35.5" H | \$158.36 |
| EW-TPOSTP5 | Primary White Shaker Turned Post - 5" W x 35.5" H | \$241.49 |
| EW-TUKIT | Primary White Shaker Touchup Kit | \$40.80 |
| EW-LRM8 | Primary White Shaker Traditional Light Rail | \$150.91 |
| EW-SCRIBE | Primary White Shaker Scribe | \$23.75 |
| EW-SHELF1296 | Primary White Shaker Shelf - 96" W x 12" D | \$206.33 |
| EW-CORSM | Primary White Shaker Basic Medium Corbel - 10.5" H | \$41.80 |
| EW-CORT | Primary White Shaker Transitional Corbel | \$117.04 |
| EW-CW2430 | Primary White Shaker Corner Wall Cabinet - 24" W x 30" H | \$269.24 |
| EW-CW2436 | Primary White Shaker Corner Wall Cabinet - 24" W x 36" H | \$302.22 |
| EW-CW2442 | Primary White Shaker Corner Wall Cabinet - 24" W x 42" H | \$383.19 |
| EW-CW2736 | Primary White Shaker Corner Wall Cabinet - 27" W x 36" H | \$345.35 |
| EW-CW2742 | Primary White Shaker Corner Wall Cabinet - 27" W x 42" H | \$410.01 |
| EW-BBP4842 | Primary White Shaker Bead Board - 48" W x 42" H x 0.25" D | \$117.04 |
| EW-BCE1596 | Primary White Shaker Book Case End - 1.5" W x 96" H x 15" D | \$170.68 |

