

RTA

CABINET STORE

May 18, 2026

Primary White Shaker Kitchen Cabinets Price List



Sink base

Model #	Item	Price
EW-CSF42	Primary White Shaker Corner Sink Front for 42" Space - 27" W	\$145.02
EW-SB30	Primary White Shaker Sink Base Cabinet - 30" W x 34.5" H	\$260.78
EW-SB33	Primary White Shaker Sink Base Cabinet - 33" W x 34.5" H	\$276.25
EW-SB36	Primary White Shaker Sink Base Cabinet - 36" W x 34.5" H	\$283.77
EW-SB42	Primary White Shaker Sink Base Cabinet w/ CS - 42" W x 34.5" H	\$325.55
EW-VSB36	Primary White Shaker Vanity Sink Base - 36" W x 34.5" H x 21" D	\$389.51
EW-VSB42	Primary White Shaker Vanity Sink Base - 42" W x 34.5" H x 21" D	\$431.30
EW-VSB48	Primary White Shaker Vanity Sink Base - 48" W x 34.5" H x 21" D	\$481.88

Filler

Model #	Item	Price
EW-FF396	Primary White Shaker Fluted Filler - 3" W x 96" H	\$101.14
EW-OLF330	Primary White Shaker Overlay for 3" x 30" Filler	\$35.52
EW-OLF336	Primary White Shaker Overlay for 3" x 36" Filler	\$41.37
EW-OLF342	Primary White Shaker Overlay for 3" x 42" Filler	\$47.64
EW-OLF630	Primary White Shaker Overlay for 6" x 30" Filler	\$71.48
EW-F396	Primary White Shaker Filler - 3" W x 96" H	\$55.99
EW-F696	Primary White Shaker Filler - 6" W x 96" H	\$112.42

End panel

Model #	Item	Price
EW-DWR3	Primary White Shaker Dish Washer End Panel	\$120.37
EW-BPLG4896	Primary White Shaker Back Panel (Long Grain) - 48" W x 96" H x 1/4" Thick	\$197.69
EW-OP3353	Primary White Shaker Oven Cabinet Overlay Panel - 33" W x 55" H	\$147.94
EW-TEP3096	Primary White Shaker Tall End Panel	\$211.88
EW-PSP4896	Primary White Shaker 1/2" Thick Finished Plywood Panel	\$328.50

Melina

Model #	Item	Price
EW-RCM8	Primary White Shaker Royal Crown Molding	\$149.21
EW-OCM8	Primary White Shaker Outside Corner Molding	\$26.33
EW-SHOE	Primary White Shaker Shoe Molding	\$21.32
EW-SCM8	Primary White Shaker Shaker Crown Molding	\$70.22
EW-BCM8	Primary White Shaker Large Crown Molding	\$143.36
EW-BEM8	Primary White Shaker Bottom Edge Molding (Narrow Light Rail)	\$71.48
EW-BAM8	Primary White Shaker Batten Molding	\$20.91
EW-FBM8	Primary White Shaker Furniture Base Molding	\$98.63
EW-CM8	Primary White Shaker Traditional Crown Molding	\$70.22
EW-COM8	Primary White Shaker Cove Crown Molding	\$117.46

Blind door

Model #	Item	Price
EW-BB36	Primary White Shaker Blind Base Cab for 36" to 39" Space - 30" W	\$345.21
EW-BB42	Primary White Shaker Blind Base Cab for 42" to 45" Space - 36" W	\$391.19
EW-BB48	Primary White Shaker Blind Base Cab for 48" to 51" Space - 48" W	\$430.47
EW-BW3636	Primary White Shaker Blind Wall Cabinet - 36" W x 36" H	\$276.25
EW-BW3642	Primary White Shaker Blind Wall Cabinet - 36" W x 42" H	\$346.88
EW-BW3630	Primary White Shaker Blind Wall Cabinet - 36" W x 30" H	\$254.00

Pantry

Model #	Item	Price
EW-P1884	Primary White Shaker Pantry - 18" W x 84" H	\$540.39
EW-P1890	Primary White Shaker Pantry - 18" W x 90" H	\$583.01
EW-P1896	Primary White Shaker Pantry - 18" W x 96" H	\$606.82

Oven

Model #	Item	Price
EW-OC3390	Primary White Shaker Oven Cabinet - 33" W x 90" H	\$876.39
EW-OC3396	Primary White Shaker Oven Cabinet - 33" W x 96" H	\$936.17
EW-OCD337	Primary White Shaker Oven Cabinet Drawer	\$226.94

Deep

Model #	Item	Price
EW-W361824	Primary White Shaker Deep Wall Cabinet - 36" W x 18" H x 24" D	\$241.98
EW-W362424	Primary White Shaker Deep Wall Cabinet - 36" W x 24" H x 24" D	\$281.27

Single door

Model #	Item	Price
EW-W930	Primary White Shaker Single Door Wall Cabinet - 9" W x 30" H	\$104.06
EW-W936	Primary White Shaker Single Door Wall Cabinet - 9" W x 36" H	\$117.86
EW-W942	Primary White Shaker Single Door Wall Cabinet - 9" W x 42" H	\$140.00
EW-W1230	Primary White Shaker Single Door Wall Cabinet - 12" W x 30" H	\$119.54
EW-W1236	Primary White Shaker Single Door Wall Cabinet - 12" W x 36" H	\$134.57
EW-W1242	Primary White Shaker Single Door Wall Cabinet - 12" W x 42" H	\$160.46
EW-W1530	Primary White Shaker Single Door Wall Cabinet - 15" W x 30" H	\$133.73
EW-W1536	Primary White Shaker Single Door Wall Cabinet - 15" W x 36" H	\$154.20
EW-W1542	Primary White Shaker Single Door Wall Cabinet - 15" W x 42" H	\$182.63
EW-W1830	Primary White Shaker Single Door Wall Cabinet - 18" W x 30" H	\$153.38

EW-W1836	Primary White Shaker Single Door Wall Cabinet - 18" W x 36" H	\$174.70
EW-W1842	Primary White Shaker Single Door Wall Cabinet - 18" W x 42" H	\$208.13
EW-W2130	Primary White Shaker Single Door Wall Cabinet - 21" W x 30" H	\$171.35
EW-W2136	Primary White Shaker Single Door Wall Cabinet - 21" W x 36" H	\$195.16
EW-W2142	Primary White Shaker Single Door Wall Cabinet - 21" W x 42" H	\$231.96
EW-VB15	Primary White Shaker Single Door Base Vanity - 15" W x 21" D	\$209.80
EW-VB18	Primary White Shaker Single Door Base Vanity-18"W x 34.5"H x 21"D	\$226.11
EW-B12	Primary White Shaker Single Door Standard Base Cabinet - 12" W	\$206.45
EW-B09	Primary White Shaker Single Door Full Height Base Cabinet - 9" W	\$150.02
EW-B15	Primary White Shaker Single Door Standard Base Cabinet - 15" W	\$225.25
EW-B18	Primary White Shaker Single Door Standard Base Cabinet - 18" W	\$242.83
EW-B21	Primary White Shaker Single Door Standard Base Cabinet - 21" W	\$262.46

Double door

Model #	Item	Price
EW-B24-2	Primary White Shaker Double Door Standard Base Cabinet - 24" W	\$290.03
EW-B27	Primary White Shaker Double Door Standard Base Cabinet - 27" W	\$358.16
EW-B30	Primary White Shaker Double Door Standard Base Cabinet - 30" W	\$368.20
EW-B33	Primary White Shaker Double Door Standard Base Cabinet - 33" W	\$399.95
EW-B36	Primary White Shaker Double Door Standard Base Cabinet - 36" W	\$408.31
EW-V24-2	Primary White Shaker Double Door Vanity - 24" W x 34.5" H x 21"	\$200.18
EW-V27	Primary White Shaker Double Door Vanity - 27" W x 34.5" H x 21"	\$233.63
EW-V30	Primary White Shaker Double Door Vanity - 30" W x 34.5" H x 21"	\$241.98
EW-V33	Primary White Shaker Double Door Vanity - 33" W x 34.5" H x 21"	\$265.81
EW-V36	Primary White Shaker Double Door Vanity - 36" W x 34.5" H x 21"	\$282.10
EW-W2430-2	Primary White Shaker Double Door Wall Cabinet - 24" W x 30" H	\$203.96
EW-W2436-2	Primary White Shaker Double Door Wall Cabinet - 24" W x 36" H	\$237.80
EW-W2442-2	Primary White Shaker Double Door Wall Cabinet - 24" W x 42" H	\$274.56
EW-W2730	Primary White Shaker Double Door Wall Cabinet - 27" W x 30" H	\$227.78
EW-W2736	Primary White Shaker Double Door Wall Cabinet - 27" W x 36" H	\$257.46
EW-W2742	Primary White Shaker Double Door Wall Cabinet - 27" W x 42" H	\$305.91
EW-W3012	Primary White Shaker Double Door Wall Cabinet - 30" W x 12" H	\$106.57
EW-W3015	Primary White Shaker Double Door Wall Cabinet - 30" W x 15" H	\$132.07
EW-W3018	Primary White Shaker Double Door Wall Cabinet - 30" W x 18" H	\$170.51
EW-W3024	Primary White Shaker Double Door Wall Cabinet - 30" W x 24" H	\$208.96
EW-W3030	Primary White Shaker Double Door Wall Cabinet - 30" W x 30" H	\$235.31
EW-W3036	Primary White Shaker Double Door Wall Cabinet - 30" W x 36" H	\$278.75
EW-W3042	Primary White Shaker Double Door Wall Cabinet - 30" W x 42" H	\$331.01
EW-W3315	Primary White Shaker Double Door Wall Cabinet - 33" W x 15" H	\$144.19
EW-W3330	Primary White Shaker Double Door Wall Cabinet - 33" W x 30" H	\$262.46
EW-W3336	Primary White Shaker Double Door Wall Cabinet - 33" W x 36" H	\$299.25
EW-W3342	Primary White Shaker Double Door Wall Cabinet - 33" W x 42" H	\$354.80
EW-W3612	Primary White Shaker Double Door Wall Cabinet - 36" W x 12" H	\$132.07
EW-W3615	Primary White Shaker Double Door Wall Cabinet - 36" W x 15" H	\$147.53
EW-W3618	Primary White Shaker Double Door Wall Cabinet - 36" W x 18" H	\$196.01
EW-W3630	Primary White Shaker Double Door Wall Cabinet - 36" W x 30" H	\$272.08
EW-W3636	Primary White Shaker Double Door Wall Cabinet - 36" W x 36" H	\$319.71
EW-W3642	Primary White Shaker Double Door Wall Cabinet - 36" W x 42" H	\$379.48
EW-W3918	Primary White Shaker Double Door Wall Cabinet - 39" W x 18" H	\$208.96
EW-W3924	Primary White Shaker Double Door Wall Cabinet - 39" W x 24" H	\$251.57
EW-W3624	Primary White Shaker Double Door Wall Cabinet - 36" W x 24" H	\$234.47

Model #	Item	Price
EW-LSB36	Primary White Shaker Lazy Susan Cabinet - 36" W x 24" D	\$738.69

Easy reach

Model #	Item	Price
EW-WER2430	Primary White Shaker Wall Easy Reach Cabinet - 24" W x 24" D x 30" H	\$295.90
EW-WER2436	Primary White Shaker Wall Easy Reach Cabinet - 24" W x 24" D x 36" H	\$314.22
EW-WER2442	Primary White Shaker Wall Easy Reach Cabinet - 24" W x 24" D x 42" H	\$359.82
EW-ER36	Primary White Shaker Easy Reach Base Cabinet - 36" W x 24" D	\$435.47

Drawer base

Model #	Item	Price
EW-DB12-3	Primary White Shaker Drawer Base Cabinet - 12" W	\$312.19
EW-DB15-3	Primary White Shaker Drawer Base Cabinet - 15" W	\$345.21
EW-DB18-3	Primary White Shaker Drawer Base Cabinet - 18" W	\$370.70
EW-DB21-3	Primary White Shaker Drawer Base Cabinet - 21" W	\$396.61
EW-DB24-3	Primary White Shaker Drawer Base Cabinet - 24" W	\$423.77
EW-DB30-3	Primary White Shaker Drawer Base Cabinet - 30" W	\$453.38
EW-VDB12	Primary White Shaker Vanity Drawer Base - 12" W x 34.5" H x 21"	\$306.74
EW-VDB15	Primary White Shaker Vanity Drawer Base - 15" W x 34.5" H x 21"	\$331.83
EW-VDB18	Primary White Shaker Vanity Drawer Base - 18" W x 34.5" H x 21"	\$357.33
EW-VDB21	Primary White Shaker Vanity Drawer Base - 21" W x 34.5" H x 21"	\$399.95
EW-VDB24	Primary White Shaker Vanity Drawer Base - 24" W x 34.5" H x 21"	\$442.58

Wine Rack

Model #	Item	Price
EW-WR3018	Primary White Shaker Wine Rack - 30" W x 18" H x 12" D	\$186.81

Other

Model #	Item	Price
EW-SPRAYCAN	Primary White Shaker Spray Can	\$8.35
EW-TBUNFOOT	Primary White Shaker Bunfoot	\$83.58
EW-TBUNFOOT2	Primary White Shaker Transitional Bunfoot	\$83.58
EW-TKS8	Primary White Shaker Toe Kick	\$17.99
EW-TPOSTP3	Primary White Shaker Turned Post - 3" W x 35.5" H	\$150.45
EW-TPOSTP5	Primary White Shaker Turned Post - 5" W x 35.5" H	\$229.42
EW-TUKIT	Primary White Shaker Touchup Kit	\$38.76
EW-LRM8	Primary White Shaker Traditional Light Rail	\$143.36
EW-SCRIBE	Primary White Shaker Scribe	\$22.56
EW-SHELF1296	Primary White Shaker Shelf - 96" W x 12" D	\$196.01
EW-CORSM	Primary White Shaker Basic Medium Corbel - 10.5" H	\$39.71
EW-CORT	Primary White Shaker Transitional Corbel	\$111.18
EW-CW2430	Primary White Shaker Corner Wall Cabinet - 24" W x 30" H	\$255.78
EW-CW2436	Primary White Shaker Corner Wall Cabinet - 24" W x 36" H	\$287.11
EW-CW2442	Primary White Shaker Corner Wall Cabinet - 24" W x 42" H	\$364.03
EW-CW2736	Primary White Shaker Corner Wall Cabinet - 27" W x 36" H	\$328.08
EW-CW2742	Primary White Shaker Corner Wall Cabinet - 27" W x 42" H	\$389.51
EW-BBP4842	Primary White Shaker Bead Board - 48" W x 42" H x 0.25" D	\$111.18
EW-BCE1596	Primary White Shaker Book Case End - 1.5" W x 96" H x 15" D	\$162.14

